

DuPont™ Kalrez® 8900

For Semiconductor Thermal Processes

Technical Information— January 2012

Product Description

DuPont™ Kalrez® 8900 perfluoroelastomer parts are a black product for all thermal processes, e.g., oxidation, diffusion furnace, metal CVD, ALD and LPCVD. It offers outstanding thermal stability, very low outgassing and excellent (low) compression set properties. Kalrez® 8900 parts exhibit excellent retention of physical properties at elevated temperatures, have excellent mechanical strength and are well-suited for both static and dynamic sealing applications. A maximum continuous service temperature of 325 °C is suggested. Short excursions to higher temperatures may also be possible. Ultrapure post-cleaning and packaging is standard for all Kalrez® 8900 parts.



Features/Benefits

- Outstanding thermal stability
- Excellent (low) compression set properties
- Very low outgassing properties
- Very low moisture content
- Excellent retention of physical properties at elevated temperatures
- Excellent resistance to fluorine gas

Suggested Applications

- Quartz Tube Seals
- Plenum Seals
- Chamber Seals
- Fittings
- Center Ring Seals

Typical Physical Properties¹

Color	Black
Hardness ² , Shore A (pellet)	73
Hardness ³ , Shore M (O-ring)	82
100% Modulus ⁴ , MPa	12.21
Tensile Strength at Break ⁴ , MPa	20.75
Elongation at Break ⁴ , %	137
Compression Set ⁵ , %	
70 hr at 204 °C	9
70 hr at 300 °C	32
70 hr at 325 °C	59
Maximum Continuous Service, Temperature ⁶ , °C	325

¹ Not to be used for specification purposes

² ASTM D2240 (pellet test specimens)

³ ASTM D2240 and D1414 (AS568 K214 O-ring test specimens)

⁴ ASTM D412 (dumbbell test specimens)

⁵ ASTM D395B and D1414 (AS568 K214 O-ring test specimens)

⁶ DuPont proprietary test method

Fabs Choose Kalrez® 8900 for Improved Performance

Kalrez® 8900 has been reported to significantly improve wafer production in semiconductor thermal process applications where aggressive gases are used during the cleaning cycle.



The miracles of science™

Case Report #11069—Exceeded 4 Month PM Target at Major AP Fabline

- Exhibited less degradation than incumbent seals after 5 months in service
- Equipment Platform — Major Japanese OEM
- Process — LPCVD Nitride
- Process Chemistry — Si_2Cl_6 , NH_3
- Cleaning Chemistry — $\text{HF} + \text{F}_2$ at 150 °C
- Seal Locations — Complete seal kit

Case Report #11932—Improved Performance vs Incumbent at Major AP Fab Line

- No evidence of degradation in aggressive seal locations after 6 months of service
- Equipment Platform — Major Japanese OEM
- Process — LPCVD Nitride
- Process Chemistry — SiH_2Cl_2 , NH_3
- Cleaning Chemistry — $\text{HF} + \text{F}_2$
- Seal Location — Complete seal kit

Case Report #12007—3x Improvement in Seal Life @ Major US Fabline

- Eliminated excessive seal leakage and particle contamination versus incumbent seals
- Equipment Platform -- HKE Quikace Furnace
- Processes -- Diffusion Radical Oxide & Pyro
- Process Chemistry -- H_2 , O_2 , N_2 , N_2O
- Cleaning Chemistry -- HCl
- Seal Locations -- G400 O-ring and upper quartz cap seal

Visit us at kalrez.dupont.com or vespel.dupont.com

Contact DuPont at the following regional locations:

North America
800-222-8377

Latin America
+0800 17 17 15

Europe, Middle East, Africa
+41 22 717 51 11

Greater China
+86-400-8851-888

ASEAN
+65-6586-3688

Japan
+81-3-5521-8484

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable and falls within the normal range of properties. It is intended for use by persons having technical skill, at their own discretion and risk. This data should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

Caution: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, discuss with your DuPont customer service representative and read Medical Caution Statement H-50103-3.

Copyright © 2012 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, Kalrez®, and Vespel® are trademarks or registered trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved.

(06/08) Reference No. KZE-A10711-00-E0112



The miracles of science™